



Twist Dynamics Hammerhead Bumper Installation Instructions



Tools Needed:

Drill with a 9/32 Drill Bit

7/16 Wrench

Phillips Head Screw Driver

Jack and Jack Stander

*It is recommended to have an assistant when installing this product.

Step 1: Assemble the three parts of the bumper to one another using the four washers, 7/16 bolts & nuts; a phillips head screwdriver, and a 7/16 wrench.

Step 2: Jack up the slingshot on either the right or left hand side. Be sure to secure Slingshot with jack stand.



Step 3: Have an assistant hold the bumper in place over the existing frame of the Slingshot as shown in above photo.



Step 4: Starting with the center portion of the Hammerhead Bumper and using an electric drill and a 9/32 drill bit, drill holes through the bottom portion of the bumper in alignment with the existing mounting holes on the bumper.



Step 5: Using a Phillips head screw driver, and a 7/16 wrench, run the larger bolts through the mounting holes that you just drilled in Step 4 and attach the nuts and washers to secure bumper in place (as shown in above photo).

*Be sure to evenly space holes drilled in the bottom of the bumper so as to ensure a proper and secure mount between the Hammerhead Bumper and the Slingshot.

Step 6: Relocate yourself to the far-right end of the bumper and repeat Steps 4 and 5 to secure the Bumper to the Slingshot. Repeat on the far-left side then proceed to secure nuts/bolts to any remaining mounting holes.

Step 9: Remove Jack and Jack Stand from underneath the vehicle.

*Always use caution when removing Jack and Jack Stand.



If you have any questions, comments, or concerns about this product, please contact Twist Dynamics directly at: (941) 323 – 5912 or email: sales@twistdynamics.com and we will be happy to help.